

# IMIDACLOPRID QUICK REFERENCE INSTRUCTIONS

**NOTE: It is the user's responsibility to read and follow the label instructions when using pesticide materials**

MIXING				
Amount of Imidacloprid Product	Amount of Water for Moderate to Wet Soil		Amount of Water for Dry to Normal Soil	
	22.6% or 21.4% 2F or 2L	1.3 fl oz water per fl oz product		3.6 fl oz water per fl oz product
75% WSP (1.6 oz)	12 fl oz water per 1.6 oz packet		24 fl oz water per 1.6 oz packet	
75% WSP (2.25 oz)	16 fl oz water per 2.25 oz packet		32 fl oz water per 2.25 oz packet	
75% WP (wetable powder)	7 oz water per oz product		14 oz water per oz product	
DOSING				
Inches in Diameter (DBH)	Dosage per Inch DBH for Moderate to Wet Soil		Dosage per Inch DBH for Dry to Normal Soil	
	Kioritz Pumps	Soil Drench	Kioritz Pumps	Soil Drench
1-11	1 pump	1/6 fl oz solution	2 pumps	1/3 fl oz solution
12-18	1.5* pumps	1/4 fl oz solution	3 pumps	1/2 fl oz solution
19-22	2 pumps	1/3 fl oz solution	4 pumps	2/3 fl oz solution
>22 should be treated two consecutive years.	3 pumps	1/2 fl oz solution	6 pumps	1 fl oz solution

If using a **Kioritz soil injector** with a **powdered product**, default to the **Dry to Normal** ratio.

If using a **Kioritz soil injector**, be sure the calibration ring is set on the red 5.

\*To get the equivalent of 1.5 pumps per hole, do 1 pump in half the holes and 2 pumps in the other half, distributing these two levels evenly around the tree. For more information, please call the Hemlock Help Line<sup>SM</sup> 706-429-8010 or visit [www.savegeorgiashemlocks.org](http://www.savegeorgiashemlocks.org).

## Kioritz Soil Injection

If applying a **powdered Imidacloprid product** by Kioritz soil injection, be sure to use the **Dry to Normal Soil** mixing and dosing column to prevent clogging the injector.

1. Make a batch of solution according to Mixing chart above.
2. Measure tree trunk diameter at breast height (DBH).
3. Rake back any leaf litter, needle duff or debris from the base of the tree so that bare soil is accessible. At a distance of no more than 12 inches from the base of the tree, make one injector hole in the soil for each inch of trunk diameter. Holes should be evenly spaced around the tree and no deeper than 2-4 inches. For trees smaller than 4 inches DBH, make a minimum of 4 very shallow holes as close to the tree trunk as possible.
4. Based on the trunk diameter, pump the injector handle the number of times shown in the Dosing chart above. Be sure to stay in the same moisture level column as you used for mixing.
5. When you're finished treating each tree, mark it to indicate it's been treated. When finished working, triple rinse injector as described in "Introduction to Treating Hemlocks."

## Soil Drench

1. Make a master batch of solution according to Mixing chart above.
2. Measure tree trunk diameter at breast height (DBH).
3. Rake back any leaf litter, needle duff or debris from the base of the tree so that bare soil is accessible. At a distance of no more than 12 inches from the base of the tree, use a piece of rebar to make one hole in the soil for each inch of trunk diameter. Holes should be evenly spaced around the tree and no deeper than 2-4 inches. For trees smaller than 4 inches DBH, make a minimum of 4 very shallow holes as close to the tree trunk as possible.
4. Treatment is done on an individual tree basis. Use the Dosing chart above to determine how many ounces of solution the tree needs by multiplying its trunk diameter by the number of ounces shown in the appropriate Dosage column. Be sure to stay in the same moisture level column as you used for mixing.
5. Use a measuring cup to measure out exactly the required amount for the tree and pour it into a larger dispensing container. Then add more water (a gallon or more) to make it easier to distribute the material evenly around the tree.
6. Pour the solution slowly into the holes to avoid runoff and be sure to use it all up on the intended tree. When you're finished treating each tree, mark it to indicate it's been treated. Give the treatment time to dry before children or pets are allowed in the area.



## SAFARI 20 SG QUICK REFERENCE INSTRUCTIONS

**NOTE:** It is the user's responsibility to read and follow the label instructions when using pesticide materials. Use **special measuring cup\*** to measure the product and a regular measuring cup to measure the water.

MIXING			
Master Batch for <b>Kioritz Soil Injector</b>		Master Batch for Soil Drench or Trunk Spray	Small Custom Batch for Soil Drench or Trunk Spray
7 oz. product with 32 oz. water (1 qt.)		3.5 oz product with 32 oz water (1 qt)	Use 2 fl. oz. water per diameter inch with amount of product indicated below.
12 oz. product with 56 oz. water		7 oz product with 64 oz water (2 qts)	
14 oz. product with 64 oz. water (2 qts)		10.5 oz product with 96 oz water (3 qts)	
21 oz. product with 96 oz. water (3 qts)		14 oz product with 128 oz water (1 gal)	
DOSING			
Inches DBH	<b>Kioritz Soil Injection:</b> PUMPS per Inch DBH	Soil Drench or Trunk Spray from Master Batch: Oz. of SOLUTION per Inch DBH	Amount of PRODUCT per inch DBH for Small Custom Batch
1 – 15	3 pumps	1 oz	0.1 oz = 3 grams
16 – 19	4 pumps	1.33 oz	0.133 oz = 4 grams
20 – 23	5 pumps	1.67 oz	0.167 oz = 5 grams
24 - 27	6 pumps	2 oz	0.2 oz = 6 grams
28 – 31	7 pumps	2.33 oz	0.233 oz = 7 grams
32 – 35	8 pumps	2.67 oz	0.267 oz = 8 grams
36 – 39	9 pumps	3 oz	0.3 oz = 9 grams
40 or more	10 pumps	3.33 oz	0.33 oz = 10 grams

Note: Apply Safari® 20SG from Feb 1 to Nov15. For more information, call 706-429-8010 or visit [www.savegeorgiashemlocks.org](http://www.savegeorgiashemlocks.org).

\*Conversion Factor: If you don't have the special measuring cup, you can use a regular measuring cup with the following conversion factor for Safari 20 SG: 3.5 oz by weight in the Safari measuring cup = 6.25 oz. by volume in a regular measuring cup.

<b>Kioritz Soil Injector</b>	<b>Soil Drench</b>	<b>Basal Trunk Spray</b>
<ol style="list-style-type: none"> <li>1. Make a master batch of solution according to Mixing chart above. Use special measuring cup for product and regular measuring cup for water.</li> <li>2. Measure trunk diameter at breast height (DBH).</li> <li>3. Rake back any leaf litter, needle duff or debris from base of tree so bare soil is accessible.</li> <li>4. Within 12" of base of tree, make 1 injector hole in soil per inch of trunk diameter. Holes should be evenly spaced around tree and no deeper than 2-4". For trees &lt;4" DBH, make a minimum of 4 very shallow holes as close to tree trunk as possible."</li> <li>5. Based on trunk diameter, pump injector handle the number of times shown in Dosing chart above.</li> <li>6. When you're finished treating each tree, mark it to indicate it's been treated. When finished working, triple rinse injector as described in "Introduction to Treating Hemlocks."</li> </ol>	<ol style="list-style-type: none"> <li>4. Within 12" of base of tree, use rebar to make 1 hole in soil per inch of trunk diameter. Holes should be evenly spaced around tree and no deeper than 2-4". For trees &lt;4" DBH, make a minimum of 4 very shallow holes as close to tree trunk as possible.</li> <li>5. Treatment is done on an individual tree basis. Use Dosing chart above, figure how many ounces of solution the tree needs by multiplying trunk diameter by number of ounces shown in Dosage column.</li> <li>6. Measure out required amount of solution and pour it into a larger dispensing container. Then add more water (a gallon or more) to make it easier to distribute the material evenly around tree.</li> <li>7. Pour solution slowly into holes to avoid runoff; use it all up on intended tree. When finished treating each tree, mark it to indicate it's been treated.</li> </ol>	<ol style="list-style-type: none"> <li>1. Make a master batch of solution according to Mixing chart above. Use special measuring cup for product and regular measuring cup for water.</li> <li>2. Measure trunk diameter at breast height (DBH).</li> <li>3. Treatment is done on an individual tree basis. Using Dosing chart above, figure how many ounces of solution the tree needs by multiplying trunk diameter by number of ounces shown in corresponding Dosage column.</li> <li>4. Measure out required amount of solution and pour it into sprayer. Set sprayer on low pressure.</li> <li>5. Position nozzle 2 inches from trunk. From 5 ½ feet above ground down to root flare, spray very slowly to avoid back-splash and allow material to be absorbed into bark. Spray until sprayer is empty so you use all the solution on intended tree.</li> <li>6. When you're finished treating each tree, mark it to indicate it's been treated.</li> </ol>

